## Honeywell Home Radiator Valves and Thermostats



# **V2000VS**

## VS type TRV Body

Presettable radiator valve with flush position

#### **APPLICATION**

Thermostatic radiator valve bodies (TRV bodies) are fitted on the supply or return of radiators or heat exchangers. Together with a radiator thermostat, for example the Thera-4, they control the room temperature by regulating the flow of hot water into the radiator or heat exchanger. The temperature of different rooms is controlled individually and energy is saved.

TRV bodies of this type have quiet operation and are fitted to the supply of radiators on two-pipe systems with medium flow rates.

The flow rate can be preset according to system requirements.

The valve insert can be replaced while the system is running and without draining using the service tool (see 'Accessories').

TRV bodies of this type are suitable for

- Honeywell Home radiator thermostats with M30  $\times$  1.5 connection
- Certain Honeywell Home MT4 actuators
- Honeywell Home Hometronic HR80 and Roomtronic HR40 actuators

#### AT-CONCEPT

AT-Concept valves share the same valve housing design. The valve insert can be replaced by any other AT-Concept valve insert, i.e. BB, KV, UBG, SL, VS, FS, FV and SC.

#### **FEATURES**

- Presettable fine-adjustment valve disc
- Tamper-proof presetting, visible when radiator thermostat is removed
- For heating systems with medium flow rates
- With extra position for system flushing
- Quiet operation
- DIN type bodies with dimensions according to EN 215, Appendix A, Series D
- NF type bodies with dimensions according to EN 215, Appendix A, Series F
- AT-Concept valve housing and insert
- Valve insert can be replaced while system is operating and without draining the system
- · Valve opening spring is not in the water
- Standard M30 x 1.5 thermostat connection



#### **DESIGN**

The thermostatic radiator valve body consists of:

- Valve housing PN10, DN10, 15 or 20 with
  - internal thread connection to DIN2999 (ISO7) for threaded, copper or precision steel pipe on inlet (compression ring fittings see 'Accessories')
  - external thread connection with union-nut and radiator tailpiece on outlet (Eurocone for DN15)
  - angle to DIN and straight to DIN bodies with dimensions according to EN215, Appendix A, Series D
  - angle to NF and straight to NF bodies with dimensions according to EN215, Appendix A, Series F
- Presettable valve insert with flush position
- Protection cap
- Union-nut and radiator tailpiece

#### **MATERIALS**

- Valve housing made of nickel-plated hot-forged brass
- Valve insert made of brass with EPDM O-rings and soft seals, stainless steel spindle and plastic presetting dial
- Protection cap made of beige plastic
- Union-nut and tailpiece made of nickel-plated brass

### **SPECIFICATIONS**

Medium:	Heating water, water quality to VDI2035
Max. operating temperature:	130 °C (262°F)
Operating pressure:	PN10
Max. differential pressure:	200 kPa (2 bar, 29 psi) – 20 kPa (0.2 bar, 2.9 psi) recommended for quiet operation
k <sub>vs</sub> (c <sub>vs</sub> )-value:	0.75 (0.87)
Nominal flow:	130 kg/h
Body-head connection:	M30 x 1.5
Closing dimension:	11.5 mm
Stroke:	2.5 mm

## **IDENTIFICATION**

- Beige protection cap, 'V' embossed on top of cap
- Beige plastic scale on top of valve insert

#### **FUNCTION**

Thermostatic radiator valves enable individual control of room temperature and thus save energy.

The TRV body is controlled by the radiator thermostat. Air from the room passing over the sensor of the radiator thermostat causes the sensor to expand when the temperature rises. The sensor acts onto the valve spindle and this causes the TRV body to close. When the temperature falls the sensor contracts and the springloaded valve spindle is opened. The TRV opens in proportion to the temperature of the sensor. Only the amount of water required to maintain the room temperature set on the radiator thermostat can flow into the radiator.

#### **PLEASE NOTE:**

- To avoid stone deposit and corrosion the composition of the medium should conform with VDI-Guideline 2035
- Additives have to be suitable for EPDM sealings
- System has to be flushed thoroughly before initial operation with all valves fully open
- Any complaints or costs resulting from non-compliance with above rules will not be accepted by Honeywell Home
- Please contact us if you should have any special requirements or needs

### **INSTALLATION EXAMPLE**




Fig. 1. Angle




Fig. 3. Horizontal angle




Fig. 2. Straight



Fig. 4. Corner angle left

## **DIMENSIONS AND ORDERING INFORMATION**




Fig. 7. Horizontal angle

Fig. 8. Corner angle left

Tab. 1 Dimensions and OS-Nos (OS=Ordering System)

Body type	DN	EN 215 certified	k <sub>vs</sub> (c <sub>vs</sub> )-value	Pipe connection	ı	L	h	Н	h <sub>2</sub>	OS-No.
For the supply										
Angle to EN 215 (D)	10	•	0.75 (0.87)	Rp <sup>3</sup> /8"	26	52	22	20	-	V2000EVS10
(Fig. 5)	15	•	0.75 (0.87)	Rp <sup>1</sup> / <sub>2</sub> "	29	58	26	20	-	V2000EVS15
	20	•	0.75 (0.87)	Rp <sup>3</sup> / <sub>4</sub> "	34	66	29	19	-	V2000EVS20
o .	10	•	0.75 (0.87)	Rp <sup>3</sup> /8"	59	85	-	25		V2000DVS10
	15	•	0.75 (0.87)	Rp <sup>1</sup> / <sub>2</sub> "	66	95	-	25	-	V2000DVS15
	20	•	0.75 (0.87)	Rp <sup>3</sup> / <sub>4</sub> "	74	106	-	25	-	V2000DVS20
Angle to EN 215 (F)	10	•	0.75 (0.87)	Rp <sup>3</sup> /8"	24	49	20	21	-	V2020EVS10
(Fig. 5)	15	•	0.75 (0.87)	Rp <sup>1</sup> / <sub>2</sub> "	26	53	23	22	-	V2020EVS15
	20		0.75 (0.87)	Rp <sup>3</sup> / <sub>4</sub> "	34	66	29	18	-	V2020EVS20
Straight to EN 215 (F)	10	•	0.75 (0.87)	Rp <sup>3</sup> / <sub>8</sub> "	50	75	-	26	-	V2020DVS10
(Fig. 6)	15	•	0.75 (0.87)	Rp <sup>1</sup> / <sub>2</sub> "	55	82	-	26	-	V2020DVS15
	20		0.75 (0.87)	Rp <sup>3</sup> /4"	74	106	-	24	-	V2020DVS20
Horizontal angle	10		0.75 (0.87)	Rp <sup>3</sup> / <sub>8</sub> "	24	50	22	33	-	V2000AVS10
(Fig. 7)	15		0.75 (0.87)	Rp <sup>1</sup> / <sub>2</sub> "	26	54	26	35	-	V2000AVS15
Corner angle, radiator	10		0.75 (0.87)	Rp <sup>3</sup> / <sub>8</sub> "	24	53	26	22	26.5	V2000LVS10
connection left (Fig. 8)	15		0.75 (0.87)	Rp <sup>1</sup> / <sub>2</sub> "	24	53	26	26	30.5	V2000LVS15
Corner angle, radiator	10		0.75 (0.87)	Rp <sup>3</sup> / <sub>8</sub> "	24	53	26	26	26.5	V2000RVS10
connection right (Fig. 8)	15		0.75 (0.87)	Rp <sup>1</sup> / <sub>2</sub> "	24	53	26	26		V2000RVS15


Note: All dimensions in mm unless stated otherwise.

## **ACCESSORIES**

	Description		Dimension	Part No.			
	FIG3/8CS	Compression fitting for COPPER and STEEL p					
anning a		Consisting of compression nut and compression ring. For valves with inte					
		Note: Support inserts have to be used for copper or soft steel pipe with 1.0 mm wall thick Max. operating temperature 120 °C, max. operating pressure 10 bar.					
		<sup>3</sup> / <sub>8</sub> ", DN10, 1 pcs.	10 mm	FIG3/8CS10			
		<sup>3</sup> / <sub>8</sub> ", DN10, 1 pcs.	12 mm	FIG3/8CS12			
		<sup>1</sup> / <sub>2</sub> ", DN15, 1 pcs.	10 mm	FIG1/2CS10			
		<sup>1</sup> / <sub>2</sub> ", DN15, 1 pcs.	12 mm	FIG1/2CS12			
		<sup>1</sup> / <sub>2</sub> ", DN15, 1 pcs.	14 mm	FIG1/2CS14			
		<sup>1</sup> / <sub>2</sub> ", DN15, 1 pcs.	15 mm	FIG1/2CS15			
		<sup>1</sup> / <sub>2</sub> ", DN15, 10 pcs.	15 mm	FIG1/2CS15-10			
		<sup>1</sup> / <sub>2</sub> ", DN15, 1 pcs.	16 mm	FIG1/2CS16			
		<sup>3</sup> / <sub>4</sub> ", DN20, 1 pcs.	18 mm	FIG3/4CS18			
		<sup>3</sup> / <sub>4</sub> ", DN20, 1 pcs.	22 mm	FIG3/4CS22			
	FIG3/8CSS	Compression fitting for COPPER and STEEL p		1103/40322			
	F10370C33		•	an autin a aut			
		Consisting of compression nut and compression For valves with internal thread.	ı rıng and sup	oport insert.			
		Note: Support inserts have to be used for copper or soft s  Max. operating temperature 120 °C, max. operating					
		<sup>3</sup> / <sub>8</sub> ", DN10	12 mm	FIG3/8CSS12			
		<sup>1</sup> / <sub>2</sub> ", DN15	12 mm	FIG1/2CSS12			
		<sup>1</sup> / <sub>2</sub> ", DN15	14 mm	FIG1/2CSS14			
		1/2", DN15	15 mm	FIG1/2CSS15			
		<sup>1</sup> / <sub>2</sub> ", DN15	16 mm	FIG1/2CSS16			
		<sup>1</sup> / <sub>2</sub> ", DN15	18 mm	FIG1/2CSS18			
		<sup>3</sup> / <sub>4</sub> ", DN20	18 mm	FIG3/4CSS18			
	FIG1/2M	Compression fitting for MULTILAYER pipe. Co	nsisting of c	ompression nut.			
		compression ring and support insert. For valves with internal thread.					
		Note: Max. operating temperature 90°C, max. operating pressure 10 bar					
		<sup>1</sup> / <sub>2</sub> ", DN15	16 mm	FIG1/2M16X2			
	VA6290	Reduction piece					
	170230	1" pipe > 1/2" valve		VA6290A260			
		$1^{1}/4$ " pipe > $1/2$ " valve		VA6290A280			
		1" pipe > $\frac{3}{4}$ " valve		VA6290A285			
		1 <sup>1</sup> /4" pipe > <sup>3</sup> /4" valve		VA6290A305			
		1 74 pipe 7 74 valve		VA0230A303			
	VA5201Axxx	Radiator tailpiece with thread up to collar					
		for valves DN10 ( $^{3}/_{8}$ ")		VA5201A010			
		for valves DN15 ( $^{1}/_{2}$ ")		VA5201A015			
Dimining		for valves DN20 ( <sup>3</sup> / <sub>4</sub> ")		VA5201A020			
	VA5204Bxxx	Extended radiator tailpiece, nickel-plated, to	be shortene	d as required			
		$^{3}/_{8}$ " x 70 mm (for DN10) thread approx. 50 mm		VA5204B010			
The state of the s		1/2" x 76 mm (for DN15) thread approx. 65 mm		VA5204B015			
		3/4" x 70 mm (for DN20) thread approx. 60 mm		VA5204B020			


	VA2200Dxxx	Manual handwheel cap					
		Presettable, with integrated locking device		VA2200D001			
	VA2202Axxx	Pressure cap – for shutting off valves on radia	tor outlet				
		for valves DN10 ( $^{3}/_{8}$ ")		VA2202A010			
		for valves DN15 ( $^{1}/_{2}$ *)		VA2202A015			
		for valves DN20 ( <sup>3</sup> / <sub>4</sub> ")		VA2202A020			
	VA5090	Sealing ring for pressure cap					
		for valves DN10 (3/8")		VA5090A010			
		for valves DN15 ( $^{1}/_{2}$ ")		VA5090A015			
		for valves DN20 ( <sup>3</sup> / <sub>4</sub> ")		VA5090A020			
	VA8200A	Service tool to replace valve insert					
TO TO THE PARTY OF			for all sizes	VA8200A001			
	VA8201	Precision presetting key					
		for all VS and FS type valves		VA8201FV03			
	VA8201	Presetting key					
MNE		for all VS, V, FS and FV type valves		VA8201FV02			
	VS1200VS	Replacement valve insert					
		VS type		VS1200VS01			

## FLOW DIAGRAM (BASED ON 2K)



Note: Presetting 8 = flush position, set by factory

#### **Tolerances for Presetting Values**



## Design example

Given: Flow rate 100 kg/h

Required: Presetting for a required pressure loss  $\Delta p$  = 90 mbar = 9 000 Pa with a P-band of 2 K Solution:

The required pressure loss is found at the intersection of the flow line with the line for the

chosen valve performance P=2K

Result: Presetting 5

#### For more information

homecomfort.resideo.com/europe



Ademco 1 GmbH Hardhofweg 40 74821 MOSBACH **GERMANY** 

Phone: +49 6261 810 Fax: +49 6261 81309

Manufactured for and on behalf of the Pittway Sàrl, La Pièce 4, 1180 Rolle, Switzerland by its Authorised Representative Ademco 1 GmbH ENOH-2103GE25 R0520

Subject to change

© 2020 Pittway Sàrl. All rights reserved. This document contains proprietary information of Pittway Sàrl and its affiliated companies and is protected by copyright and other international laws. Reproduction or improper use without specific written authorisation of Pittway Sàrl is strictly forbidden. The Honeywell Home trademark is used under license from Honeywell International Inc.

